

FIG. 1




FIG. 2




FIG. 3A




FIG. 3B




FIG. 4




FIG. 5




FIG. 6A

API for UI

1. EPGChannelLineup

Description Call this function to get a list of brief show information for a given range of channel numbers and time frame. The returned show array is sorted in the order of channel number and show beginning time.

Prototype Boolean EPGChannelLineup(const line_up & sline, show_info * const sinfo, int * const sorder, int &length, query_error & err);

Parameters •sline: IN PARAMETER. This structure specifies time grids and the range of channel numbers. The data structure is defined as:

```
struct line_up
{
    time_t time_grid_start;
    time_t time_grid_end;
    int channel_id_start;
    int channel_id_end;
}
```

•sinfo: OUT PARAMETER. sinfo is an array of type show_info.

```
struct show_info
{
    int channel_number;
    char call_letter[9];
    time_t begin_time;
    short duration;
    unsigned char cat_index;
    unsigned char sub_cat_index;
    char short_title[22];
    long reference_number;
}
```

•sorder: OUT PARAMETER. It stores the order of shows sorted in channel number and time. For example, sinfo[sorder[0]] is the first show, sinfo[sorder[1]] the second, etc.

•length: IN OUT PARAMETER. As an in parameter, length is the dimension of sinfo and sorder, as an out parameter, it is the actual number of shows stored in sinfo and sorder, provided the number is less than the input length. Otherwise, FALSE is returned and err is populated with messages.

•Err: OUT PARAMETER. This parameter holds error information if error occurs. Non-zero err_code means something wrong in the call. Query_error is defined as

```
struct query_error
{
    int err_code;
    char err_msg[100];
}
```

Return TRUE: Success

Value FALSE: Fails to prepare tables for data loading

2. EPGShowDescription

Description This function returns a detailed show data. In order to get detailed show info, caller needs to pass the beginning time (or date) and reference number of the show. Reference number of a show is obtained by calling EPGChannelLineup function.

Prototype Boolean EPGShowDescription(show_brief_info &sbrief, show_description & sdesc, query_error & err);

Parameters • sbrief: IN PARAMETER. The struct show_brief_info is defined as

```
{
    time_t date;
    long reference_number;
```

FIG. 6B

- ```
}
• sdesc: OUT PARAMETER. Detailed description of a show, including category, description,
 etc. The data structure is defined as
 struct show_description
 {
 char rest_of_title[100];
 char short_description[64];
 char description[801];
 char category[13];
 char subcategory[13];
 short year_produced;
 float stars;
 bool re_run;
 bool live;
 bool closed_caption;
 bool stereo;
 char tv_rating[13];
 char mpaa_rating[5];
 }
• err: OUT PARAMETER.
```
- Return** TRUE: Success  
**Value** FALSE: Fails to prepare tables for data loading.

### 3. EPGFilter

- Description** To get a list of shows having specified category-index and subcategory-index. Category-index and subcategory-index are numbers between 0 to 15.
- Prototype** Boolean EPGFilter(show\_cat\_info &scat, show\_info \* const sinfo, int \* const sorder, int &length, query\_error & err);
- Parameters**
- scat: IN PARAMETER. The data struct show\_cat\_info is defined as

```
struct show_cat_info
{
 short cat_index;
 short sub_cat_index;
 time_t begin_time;
 unsigned char updown_flag;
}
```

Above data structure specifies category index, subcategory index, beginning time of a search, and forward or backward search flag. updown\_flag=1 means forward search, 0 means backward search. The search is limited among the shows of the same day as the specified beginning time.
  - sinfo: OUT PARAMETER. sinfo is an array of type show\_info.
  - sorder: OUT PARAMETER. It stores the order of shows sorted in channel number and time. For example, sinfo[sorder[0]] is the first show, sinfo[sorder[1]] the second, etc.
  - length: IN OUT PARAMETER. As an in parameter, length is the dimension of sinfo and sorder, as an out parameter, it is the actual number of shows stored in sinfo and sorder, provided the number is less than the input length. Otherwise, FALSE is returned and err is populated with messages.
  - Err: OUT PARAMETER. This parameter holds error information if error occurs. Non-zero err\_code means something wrong in the call.
- Return** TRUE: Success  
**Value** FALSE: Fails to prepare tables for data loading.



**FIG. 7**




FIG. 8A

API for Data Loader

1. TsiCallback::StartLoading

**Description** StartLoading is responsible for preparing database tables for the data loading. Therefore, this function must be called before data loading. After data loading is done, EndLoading function shall be called.

**Prototype** Boolean StartLoading()

**Parameters** None

**Return** TRUE: Success

**Value** FALSE: Fails to prepare tables for data loading.

2. TsiCallback::StartSip

**Description** StartSip marks the beginning of the data loading of a show information packet. A show information packet contains 4-hour show data for one channel. EndSip indicates the end of the data loading of one packet.

**Prototype** Boolean StartSip()

**Parameters** None

**Return** TRUE: Success

**Value** FALSE: Fails to prepare tables for data loading.

3. TsiCallback::WriteSip

**Description** WriteSip inserts one or couple of show data into database tables.

**Prototype** Boolean WriteSip(const SipHeader &shdr, const Showinfo \*psi, int length)

**Parameters**

- shdr: IN PARAMETER. SipHeader contains common data shared by show data stored in the array Showinfo.  
struct  
TUNECHAN {  
    unsigned char type;           // b0-2: 0:OTA 1:cable 2:satellite 3-7:reserved  
                                  // b3:digital b4:dual A/B cable trunk b5-7:rsvd  
    unsigned short minor;       // up to 10 bits of digital minor channel  
    unsigned short major;       // up to 10 bits of digital major channel, or analog channel  
}  
struct SipHeader  
{  
    short channel\_id;            // unique channel ID  
    TUNECHAN tune\_channel;       // see struct definition above  
    char channel\_name[9];       // (null terminated string)  
    unsigned char day\_of\_week;   // 0,1,2,6 for Sun, ..., Saturday, respectively  
    char date[9];                // YYYYMMDD null terminated  
                                  // on 4 hour intervals (0, 4, 8, 12, 16, 20)  
}  
• psi: IN PARAMETER. Showinfo is defined as  
struct Showinfo  
{  
    char short\_title[22];        // short title, as displayed on grid titles  
    char rest\_of\_title[100];     // concatenated with short title, the complete show title  
    char short\_description[64];  // short description. Enough descriptive text to fit 3x21  
                                  // display. (includes ratings for movies, teams for sports,  
                                  // subjects for talk shows, etc. char null terminated.  
    char long\_description[801];  // with short description, complete description  
                                  // null terminated  
    char begin\_time[15];

**FIG. 8B**

```
// Show starting time with format of YYYYMMDDHHMI
// null terminated. MM takes a value of 01, ..., 12;
// DD takes a value of 01, ..., 31; HH takes a value of 00, ..., 23;
// MI takes a value from 00 to 59.
char end_time[15]; // as above, used for performance purpose
int duration; // in minutes
char category[13]; // category name, null terminated
unsigned char cat_index;
char subcategory[13]; // sub-category name, null terminated
unsigned char sub_cat_index;
short year_produced; // four digits, e.g., 1998. For search purpose
float stars; // 0, 0.5, 1, 1.5, 2, ..., 4.5, 5 for search purpose
bool re_run;
bool live;
bool closed_caption;
bool stereo;
char TV_rating[13]; // "TVMA-FVDLVS", "TVY-LV", ..., null terminated
char mpaa_rating[5]; // "NC17", "X", ..., null terminated
};
psi is the pointer of the array Showinfo psi[length].
• length: IN PARAMETER. length tells how many show records in the array psi.
```

**Return** TRUE: Success  
**Value** FALSE: Fails to prepare tables for data loading.


#### 4. TsipCallback::EndSip

**Description** EndSip marks the end of the data loading of a show information packet.  
**Prototype** Void EndSip()  
**Parameters** None  
**Return** Void  
**Value**

#### 5. TsipCallback::EndLoading

**Description** After data loading is successfully completed, Data Loader calls EndLoading to invoke a sequence of actions on the database tables, such as clean up temporary tables and etc. If, for some reason, this API is not called, then show data for UI will not be updated.  
**Prototype** Void EndLoading()  
**Parameters** None  
**Return** Void  
**Value**

**FIG. 9**



**FIG. 10A**

**API for Channel Mapping**

**1. MapGet**

**Description** This function returns an array of Channel Mapping data to the caller. Channel Mapping describes the mapping among Channel, Call letter, Category, and Channel Id.

**Prototype** Boolean MapGet(channel\_map \* const minfo, int \* const sorder, int &length, query\_error & err)

**Parameters**

- minfo: OUT PARAMETER. The pointer minfo points to an array of channel\_map. The struct channel\_map is defined as  
struct channel\_map  
{  
    char call\_letter[9];  
    unsigned short channel id;  
    unsigned short channel;  
    unsigned short cat;  
};
- sorder: OUT PARAMETER. It stores the order of Channel Mappings sorted in channel number.
- length: IN OUT PARAMETER. As an in parameter, length is the dimension of minfo and sorder, as an out parameter, it is the actual number of shows stored in minfo and sorder, provided the number is less than the input length. Otherwise, FALSE is returned and err is populated with messages.
- Err: OUT PARAMETER. This parameter holds error information if error occurs. Non-zero err\_code means something wrong in the call.

**Return** TRUE: Success

**Value** FALSE: Fails to prepare tables for data loading.

**2. MapSet**

**Description** Caller can set Channel Information by calling this function. Inside of MapSet, it checks each element of the array minfo against the records in the database. If the call letter exists in the database, then update the row by the new data from minfo; if call letter doesn't exist in the database, then insert a new row into the database.

**Prototype** Boolean MapSet(channel\_map \* const minfo, int &length, query\_error & err)

**Parameters**

- minfo: IN PARAMETER. The parameter minfo is an array of channel\_map. The struct channel\_map is defined as  
struct channel\_map  
{  
    char call\_letter[9];  
    unsigned short channel id;  
    unsigned short channel;  
    unsigned short cat;  
};
- length: IN PARAMETER. It is the actual number of Channel Mappings stored in minfo.
- Err: OUT PARAMETER. Non-zero err\_code means something wrong in the call.

**Return** TRUE: Success

**Value** FALSE: Fails to prepare tables for data loading.

**3. MiniGuideGet**

**Description** To get Mini Guide data. Mini Guide shows the mapping between Category and Channel. At present, there are about 12 categories. Each Category owns a segment of Channels.

**Prototype** Boolean MiniGuideGet(mini\_guide \* const minfo, int \* const sorder, int &length, query\_error & err)

FIG. 10B

**Parameters**

- minfo: OUT PARAMETER. minfo is an array of mini\_guide. The data struct mini\_guide is defined as  
struct  
{  
    char name[15];           // Category  
    unsigned short channel;   // Channel Number  
    unsigned short offline;   // Channel number starts at  
    unsigned short start;     // Channel segment starts at  
    unsigned short end;       // Channel segment ends at  
    unsigned short dup\_start; // Local Channel starts at  
}
- sorder: OUT PARAMETER. The order of Mini Guides by channel number.
- length: IN OUT PARAMETER. As an in parameter, length tells the dimension of minfo and sorder, as an out parameter, it is the actual number of Mini Guides stored in minfo and sorder, provided the number is less than the input length. Otherwise, FALSE is returned.
- Err: OUT PARAMETER. Non-zero err\_code means something wrong in the call.

**Return** TRUE: Success  
**Value** FALSE: Fails to prepare tables for data loading.

#### 4. MiniGuideSet

**Description** Caller can set Mini Guides by calling this function. Inside of MiniGuideSet, each element of the array minfo is checked against the records in the database. If a category exists in the database, then update the row by the new data from minfo; if a category doesn't exist in the database, then insert a new row into the database.


**Prototype** Boolean MiniGuideSet(mini\_guide \* const minfo, int &length, query\_error & err)  
**Parameters**

- minfo: IN PARAMETER. The pointer minfo points to an array of mini\_guide.
- length: IN PARAMETER. It is the actual number of Mini Guides stored in minfo.
- Err: OUT PARAMETER. Non-zero err\_code means something wrong in the call.


**Return** TRUE: Success  
**Value** FALSE: Fails to prepare tables for data loading.

# FIG. 11

## (Partial Software)



**FIG. 12**





**FIG. 13**




FIG. 14

```
struct adr_hdr;
{
 char _name[30];
 char f_name[30];
 char c_date[15];
 long t_row;
 long a_row;
 long na_row;
 short hdr_len;
 short row_start;
 short row_len;;
 short row_hdr_len;
 short row_bdy_len;
 short row_hdr_start;
};
```

where


- Name: Table name
- C\_date: When the table is created, in the form “YYYYMMDDHHMISS”
- F\_name: the file where the data is stored
- T\_row: Total number of initialized rows
- Na\_row: Next available row id for insertion
- Hdr\_len: length of the header
- Row\_start: where the data (row) start (=hdr\_len);
- Row\_len: the length of a row
- Row\_hdr\_len: length of the row header
- Row\_bdy\_len: the length of the row-body
- Row\_hdr\_start: Where the row-header starts

```
Struct row_hdr
{
 long row_id;
 long next_available_row;
 char usage;
}
```

where

- Row\_id: row id of the row. Increased by one each time
- Next\_avaiable\_row: row id of the next available row for insertion.
- usage: ‘N’ means available; ‘Y’ means used.

# FIG. 15



**FIG. 16**

